List of storage features

1 Console box
2 Bottle holders
3 Auxiliary boxes
4 Glove box
5 Cup holders

CAUTION

- **Items that should not be left in the storage spaces**

  Do not leave glasses, lighters or spray cans in the storage spaces, as this may cause the following when cabin temperature becomes high:

  - Glasses may be deformed by heat or cracked if they come into contact with other stored items.
  - Lighters or spray cans may explode. If they come into contact with other stored items, the lighter may catch fire or the spray can may release gas, causing a fire hazard.

Glove box

The glove box can be opened by pressing the lock release button and locked and unlocked using the mechanical key.

1 Open
2 Lock
3 Unlock

CAUTION

Caution while driving

Keep the glove box closed when not in use. In the event of sudden braking, an accident may occur due to an occupant being struck by the open glove box or the items stored inside.

Console box

Lift the lid while pushing the knob to release the lock.

Tray in the console box

The tray slides forward/backward and can be removed.

CAUTION

Caution while driving

Keep the console box closed when not is use. In the event of sudden braking, an accident may occur due to an occupant being struck by the open console box or the items stored inside.

Cup holders

■ **Cup holder partition**

The partition in the cup holder can also be used to store a small cup or can.

⚠ CAUTION

■ **Items unsuitable for the cup holder**

Do not place anything other than cups or aluminum cans in the cup holders. Other items may be thrown out of the holders in the event of an accident or sudden braking, causing injury. If possible, cover hot drinks to prevent burns.

Bottle holders

n **When using the bottle holder**

l When storing a bottle, close the cap.

l The bottle may not be stored depending on its size or shape.

NOTICE

n **Items that should not be stowed in the bottle holders**

Put the cap on before stowing a bottle. Do not place open bottles in the bottle holders, or glasses and paper cups containing liquid. The contents may spill and glasses may break.

Auxiliary boxes

Type A

Press in the lid.

This box is useful for temporarily storing sunglasses and similar small items.

Type B

Type C (if equipped)

Type D (if equipped)

⚠ CAUTION

■ **Caution while driving (type A)**

Keep the auxiliary boxes closed when not in use. In the event of sudden braking, an accident may occur due to an occupant being struck by an open auxiliary box or the items stored inside.

■ **Items unsuitable for storing (type A)**

Do not store items heavier than 0.44 lb. (200 g).
Doing so may cause the auxiliary box to open and the items inside may fall out, resulting in an accident.